

EV7401M Single output thermoregulator

GB ENGLISH

1 GETTING STARTED


1.1 Important

Read these instructions carefully before installing and using the instrument and follow all additional information for installation and electrical connection.

Keep these instructions close to the instrument for future consultations.

1.2 Installing the instrument

Panel mounting, with the screw brackets supplied by the builder; dimensions in mm (in).




DIMENS.	MINIMUM	TYPICAL	MAXIMUM
A	68.0 (2.677)	68.0 (2.677)	68.7 (2.704)
B	68.0 (2.677)	68.0 (2.677)	68.7 (2.704)

Additional information for installation:

- 75 (2.952) is the maximum depth with spring terminal blocks
- 90 (3.543) is the maximum depth with extractable terminal blocks
- the maximum panel thickness must be 4 mm (0.157 in)
- position the brackets as indicated; moderate the clamping torque, in order not to damage box and brackets
- working conditions (ambient temperature, humidity, etc.) must be between the limits indicated in the technical data
- do not install the instrument close to heating sources (resistances, hot air ducts, etc.), locations subject to direct sunlight, rain, humidity, dust, mechanical vibrations or bumps, devices provided with big magnetos (big speakers, etc.)
- according to the safety norms, the protection against electrical parts must be ensured by a correct installation of the instrument; the parts that ensure the protection must be installed so that you can not remove them if not by using a tool.

1.3 Wiring diagram



WITH REFERENCE TO THE OPTION IN THE OUTLINE:
• If the instrument is supplied with 24 Vac, between terminals 9 and 11 there will be a potential difference of 230 Vac (analogously if the instrument is supplied with 230 Vac, between terminals 9 and 10 there will be a potential difference of 24 Vac not SELV); these voltages must not absolutely be used.

WITH REFERENCE TO THE UNDERLINED OPTION:
• If the instrument is supplied with 24 Vac, protect terminal 9 or terminal 10 with a fuse (160 mA T).

Additional information for electrical connection:
• do not operate on the terminal blocks with electrical or pneumatic screws
• if the instrument has been moved from a cold to a warm location, the humidity will condense on the inside; wait about an hour before sup-

plying the instrument

- test the working power supply voltage, working electrical frequency and working electrical power of the instrument; they must correspond with the local power supply
- disconnect the local power supply before servicing the instrument
- provide the probe with a protection able to protect it against contacts with metal parts or use an insulated probe
- do not use the instrument as safety device
- for repairs and information concerning the instrument please contact Evco sales network.


2 OPERATION

2.1 Preliminary information

You can configure the instrument to work in two different modes, according to parameter r4.


2.2 Operation with parameter r4 = 0 ("cooling" action)

temp.
load
time



2.3 Operation with parameter r4 = 1 ("heating" action, default value)

temp.
load
time



3 WORKING SETPOINT

3.1 Preliminary information

You can set the working setpoint through parameter SP1, too.

3.2 Setting the working setpoint

- press or 4 s: the instrument will show "PA"
- press or in 15 s (look at parameters r2 and r3, too)
- press or do not operate 15 s.

4 CONFIGURATION PARAMETERS

4.1 Setting configuration parameters

Configuration parameters are arranged on two levels.

To gain access the first level:

- press and 4 s: the instrument will show "PA"

To select a parameter:

- press or

To modify a parameter:

- press

- press or in 15 s

- press or do not operate 15 s.

To gain access the second level:

- gain access the first level

- press or to select "PA"

- press

- press or in 15 s to set "-19"

- press or do not operate 15 s

- press and 4 s: the instrument will show "SP1".

To quit the procedure:

- press and 4 s or do not operate 60 s.

4.2 Restoring default configuration parameters

- press and 4 s: the instrument will show "PA"

- press or in 15 s to set "149"

- press or do not operate 15 s

- press and 4 s: the instrument will show "SEL" flashing.

- press or do not operate 15 s

- press or in 15 s: the value will not change

- press or do not operate 15 s

- press 4 s: this will reset the instrument.

5 USER INTERFACE

5.1 Preliminary information

During the normal operation the instrument shows one of the following quantities, according to parameter P6:

- the room temperature (LED will be switched off)
- the working setpoint (LED will be lit).

5.2 Silencing the buzzer

- press a button.

5.3 Locking the keyboard

- press 4 s: the instrument will show .

To unlock the keyboard:

- press 4 s.

Conservare queste istruzioni con lo strumento per consultazioni future.

6 SIGNALS

6.1 Signals

LED	MEANING
	LED working setpoint if it is switched off, the instrument will show the room temperature (parameter P6)
	if it is lit, the instrument will show the working setpoint (parameter P6)
	if it flashes, the modification of the working setpoint will be running
	LED load if it is lit, the load will be turned on
	if it flashes, the modification of the working setpoint will be running or a load protection will be running (parameters C1 or C2)
	LED Fahrenheit degree if it is lit, the unit of measure of the temperature will be Fahrenheit degree (parameter P4)
	LED Celsius degree if it is lit, the unit of measure of the temperature will be Celsius degree (parameter P4)
	INDICAT. MEANING if it flashes, the keyboard will be locked (look at paragraph 5.3)

CODE	MEANING
AL1	First temperature alarm (parameters A1, and A3) Remedies: ▪ check the room temperature Effects: ▪ no effect
AL2	Second temperature alarm (parameters A5 and A7) Remedies: ▪ check the room temperature Effects: ▪ no effect

CODE	MEANING
PR1	Room probe alarm Remedies: ▪ check the kind of probe (parameter P0) ▪ check the integrity of the probe ▪ check the connection instrument-probe ▪ check the room temperature Effects: ▪ the load will be turned off

CODE	MEANING
ERR	Internal alarm Remedies: ▪ switch off the power supply of the instrument; unless the alarm disappears, you will have to change the instrument Effects: ▪ the load will be turned off

CODE	MEANING
PR1	Allarme sonda ambiente Rimedi: ▪ verificare il tipo di sonda (parametro P0) ▪ verificare l'integrità della sonda ▪ verificare la connessione strumento-sonda ▪ verificare la temperatura ambiente Conseguenze: ▪ il carico viene spento

CODE	MEANING
ERR	Allarme interno Rimedi: ▪ interrompere l'alimentazione dello strumento; se l'allarme non scompare, è necessario sostituire lo strumento Conseguenze: ▪ il carico viene spento

CODE	MEANING
PR1	Allarme sonda ambiente Rimedi: ▪ verificare il tipo di sonda (parametro P0) ▪ verificare l'integrità della sonda ▪ verificare la connessione strumento-sonda ▪ verificare la temperatura ambiente Conseguenze: ▪ il carico viene spento

CODE	MEANING
ERR	Allarme interno Rimedi: ▪ interrompere l'alimentazione dello strumento; se l'allarme non scompare, è necessario sostituire lo strumento Conseguenze: ▪ il carico viene spento

CODE	MEANING
PR1	Allarme sonda ambiente Rimedi: ▪ verificare il tipo di sonda (parametro P0) ▪ verificare l'integrità della sonda ▪ verificare la connessione strumento-sonda ▪ verificare la temperatura ambiente Conseguenze: ▪ il carico viene spento

CODE	MEANING
ERR	Allarme interno Rimedi: ▪ interrompere l'alimentazione dello strumento; se l'allarme non scompare, è necessario sostituire lo strumento Conseguenze: ▪ il carico viene spento

- presser ou d'ici 15 s pour configurer "149"
- presser ou bien ne rien manipuler pendant 15 s
- presser et pendant 4 s: l'appareil visualise "SEL" clignotant.
- presser l'appareil visualise "1"
- presser ou d'ici 15 s: la valeur ne change pas
- presser ou bien ne rien manipuler pendant 15 s.
- presser pendant 4 s: l'appareil s'initialise.

5 INTERFACE DE L'UTILISATEUR

5.1 Notices préliminaires

Pendant le fonctionnement normal l'appareil visualise une des suivantes grandeurs, selon le paramètre P6:

- la température de l'ambiance (la LED est éteinte)
- le point de consigne (la LED est allumée).

5.2 Acquit des alarmes

- presser une touche.

5.3 Blocage du clavier

- presser pendant 4 s: l'appareil visualise -nn-

Pour débloquer le clavier:

- presser pendant 4 s.

6 SIGNALISATIONS

6.1 Signalisations

LED	SIGNIFICATION
	LED point de consigne si éteinte, l'appareil visualise la température de l'ambiance (paramètre P6) si allumée, l'appareil visualise le point de consigne (paramètre P6) si clignote, la modification du point de consigne est en cours
out 1	LED charge si allumée, la charge est en marche si clignote, la modification du point de consigne est en cours ou une protection de la charge est en cours (paramètres C1 ou C2)
	LED degré Fahrenheit si allumée, l'unité de mesure des températures est le degré Fahrenheit (paramètre P4)
	LED degré Celsius si allumée, l'unité de mesure des températures est le degré Celsius (paramètre P4)

INDICAT.	SIGNIFICATION
-nn-	si clignote, le clavier est bloqué (voir le paragraphe 5.3)

7 ALARMES

7.1 Alarms

CODE	SIGNIFICATION
AL1	Première alarme de température (paramètre A1 et A3) Remédies: • vérifier la température de l'ambiance Conséquences: • aucun conséquence
AL2	Seconde alarme de température (paramètre A5 et A7) Remédies: • vérifier la température de l'ambiance Conséquences: • aucun conséquence
8.1 Diagnostique interne	
CODE	SIGNIFICATION

PR1	SIGNIFICATION
	Alarme sonde ambience Remédies: • vérifier le type de sonde (paramètre P0) • vérifier l'intégrité de la sonde • vérifier le raccordement appareil-sonde • vérifier la température de l'ambiance Conséquences: • la charge est éteinte
Err	Alarme interne Remédies: • interrompre l'alimentation de l'appareil; si l'alarme ne disparaît pas, il est nécessaire de changer l'appareil Conséquences: • la charge est éteinte

9 DONNEES TECHNIQUES

9.1 Données techniques

Boîtier:	autoextinguible gris.
Degré de protection de la face avant:	IP 65.
Connecteurs:	borniers débrochables ou borniers à ressort (alimentation, entrée et sortie).
Température ambiante:	de 0 à 55 °C (de 32 à 131 °F, 10 ... 90% d'humidité relative sans condensation).
Alimentation:	230 Vca (bornes 9 et 11) ou 24 Vca (bornes 9 et 10), 50/60 Hz, 2 VA (230 Vca, 115 Vca ou 24 Vca, 50/60 Hz, 2 VA sur demande).
Buzzer d'alarme:	incorporé.
Entrées de mesure:	1 (sonde ambience) pour sondes PTC/NTC, thermocouples J/K, sondes Pt 100 2/3 fils ou capteurs de courant 0-20/4-20 mA.
Plage de travail:	de -50 à 150 °C (-60 à 300 °F) pour sonde PTC, de -40 à 110 °C (-40 à 230 °F) pour sonde NTC, de -100 à 700 °C (-130 à 1.300 °F) pour thermocouple J, de -100 à 1.150 °C (-130 à 2.000 °F) pour thermocouple K, de -100 à 650 °C (-130 à 1.200 °F) pour sonde Pt 100 2/3 fils.

Résolution:	0,1 °C/1 °F, 0,1 °C/1 °F pour capteurs de courant 0-20/4-20 mA, 0,1 °C/1 °F autrement.
Sorties:	1 relais inverseur (8A @ 250 Vca le contact NO, 3A @ 250 Vca le contact NF).

GB ENGLISH				
10 WORKING SETPOINTS AND CONFIGURATION PARAMETERS				
10.1 Working setpoints				
PARAM	MIN.	MAX.	U.M.	DEF.
r2	r3		°C/°F (1)	0.0
WORKING SETPOINTS				
SP1	r2	r3	°C/°F (1)	0.0
PARAM	MIN.	MAX.	U.M.	DEF.
CA1	-25.0	25.0	°C/°F (1)	0.0
PARAM	MIN.	MAX.	U.M.	DEF.
r1	0.1	99.9	°C/°F (1)	1.0
MEASURE INPUTS				
CA1	-25.0	25.0	°C/°F (1)	0.0
PARAM	MIN.	MAX.	U.M.	DEF.
P0	0	7	---	2
P1	0	2	---	1
P2	-99.0	999.0	points	-20.0
P3	-99.0	999.0	points	80.0
P4	0	3	---	0
P5	0	2	---	0
P6	0	1	---	0
PARAM	MIN.	MAX.	U.M.	DEF.
r1	0.1	99.9	°C/°F (1)	1.0
r2	-99.0	r3	°C/°F (1)	0.0
r3	999.0	°C/°F (1)	350.0	
PARAM	MIN.	MAX.	U.M.	DEF.
C1	0	999	s	0
C2	0	999	s	0
PARAM	MIN.	MAX.	U.M.	DEF.
A1	-99.0	999.0	°C/°F (1)	0.0
A2	0	999	min	0
A3	0	4	---	0
A4	0	999	min	0
PARAM	MIN.	MAX.	U.M.	DEF.
A5	-99.0	999.0	°C/°F (1)	0.0
A6	0	999	min	0
A7	0	4	---	0
REGULATOR				
REGOLATORE				
SECOND LEVEL CONFIGURATION PARAMETERS				
PARAM	MIN.	MAX.	U.M.	DEF.
P1	0	2	---	1
P2	-99.0	999.0	points	80.0
P3	-99.0	999.0	points	80.0
P4	0	3	---	0
P5	0	2	---	0
P6	0	1	---	0
PARAM	MIN.	MAX.	U.M.	DEF.
r1	0.1	99.9	°C/°F (1)	1.0
r2	-99.0	r3	°C/°F (1)	0.0
r3	999.0	°C/°F (1)	350.0	
PARAM	MIN.	MAX.	U.M.	DEF.
C1	0	999	s	0
C2	0	999	s	0
PARAM	MIN.	MAX.	U.M.	DEF.
A1	-99.0	999.0	°C/°F (1)	0.0
A2	0	999	min	0
A3	0	4	---	0
A4	0	999	min	0
PARAM	MIN.	MAX.	U.M.	DEF.
A5	-99.0	999.0	°C/°F (1)	0.0
A6	0	999	min	0
A7	0	4	---	0
FIRST LEVEL CONFIGURATION PARAMETERS				
PARAM	MIN.	MAX.	U.M.	DEF.
P1	0	2	---	1
P2	-99.0	999.0	points	80.0
P3	-99.0	999.0	points	80.0
P4	0	3	---	0
P5	0	2	---	0
P6	0	1	---	0
PARAM	MIN.	MAX.	U.M.	DEF.
r1	0.1	99.9	°C/°F (1)	1.0
r2	-99.0	r3	°C/°F (1)	0.0
r3	999.0	°C/°F (1)	350.0	
PARAM	MIN.	MAX.	U.M.	DEF.
C1	0	999	s	0
C2	0	999	s	0
PARAM	MIN.	MAX.	U.M.	DEF.
A1	-99.0	999.0	°C/°F (1)	0.0
A2	0	999	min	0
A3	0	4	---	0
A4	0	999	min	0
PARAM	MIN.	MAX.	U.M.	DEF.
A5	-99.0	999.0	°C/°F (1)	0.0
A6	0	999	min	0
A7	0	4	---	0
SECOND LEVEL CONFIGURATION PARAMETERS				
PARAM	MIN.	MAX.	U.M.	DEF.
P1	0	2	---	1
P2	-99.0	999.0	points	80.0
P3	-99.0	999.0	points	80.0
P4	0	3	---	0
P5	0	2	---	0